

A man in a blue sweater is holding a baby in a nursery. The room features dark grey walls, a large window with white roller shutters, and three framed pictures of animals. A white crib and a white dresser are visible in the foreground.

Moments Guide

ROLLER SHUTTERS




04



09



10



14

- 2. Contents
- 3. Congratulations!
- 5. Research and Development
- 6. Spring clean
- 8. Safe use
- 11. Declaration of conformity IIa
- 13. Warranty registration
- 14. Product code



CONGRATULATIONS!

Congratulations on your new Verano® product(s)! Now it's time to enjoy it. We want it to be all about you and will therefore ensure you can use our products to turn your house into a safe and comfortable home. We would like to provide you with a number of tips in this 'Moments guide', which will allow you to continue enjoying your product(s) for many years to come. And finally, we would really love to hear from you on one of our social media pages!

Yours sincerely,

Harrie van Zutphen

CEO

RESEARCH AND DEVELOPMENT

Your roller shutter profiles have been made from top quality aluminium. One of the main advantages of aluminium is that it's strong and solid, but also very light-weight. Aluminium boasts characteristics which make it almost maintenance-free and warranty a long life. All these elements combined have made aluminium the perfect material to use as a basis for your roller shutter.

We are proud owners of the AluEco certificate. The AluEco foundation promotes sustainability and ensures aluminium is recycled into top quality products, with a minimal environmental impact.

SHARE YOUR MOMENTS!

#veranomoment



SPRING CLEAN!

It goes without saying you are going to want to enjoy your Verano® product(s) for as long as possible. Cleaning the product will certainly contribute to a long life. That's why we will provide you with a step-by-step plan to help you with the cleaning. We recommend cleaning the roller shutter at least once a year. Make sure the roller shutter is disconnected from the power supply before you start cleaning!

WHAT WILL YOU NEED?



DRY LUBRICANT



CLEANING PRODUCTS
WITH A LOW PH VALUE
(<7.5)



LUKEWARM WATER
(MAX 35°C)



BRUSH

ALSO CHECK:

Verano® products require little maintenance and have an incredibly long life. However, in the unlikely event of a product malfunction, we would like to ask you to contact your Verano® partner immediately. Make sure you check the following before you start cleaning your products:

- Aluminium profiles
- Distortion of the product
- Deviating sound when opening/closing

CLEANING THE ROLLER SHUTTER

STEP 1

Remove any dirt

Remove loose dirt with a brush.



STEP 2

Cleaning the profiles

The profiles can be cleaned with lukewarm water and a cleaning product with a pH value lower than 7.5. Avoid using scouring pads and high pressure equipment!



STEP 3

Lubricate parts

You can apply a dry lubricant, such as silicon spray, to the plastic guidance blocks, rubbers and the aluminium guidance profiles.



SAFE USE

We think it's important for the safety of your living environment to remain guaranteed! We would therefore like to ask you to consider the following safety measures before you start using your product:



The tubular motor is thermally protected, in the event of overheating, the protection is activated and you are temporarily unable to use the product. As soon as the engine has cooled, the thermal protection switches off automatically.



Don't use the roller shutter when ice has formed on the armour, as this can cause damage to the suspension and slats.



Only operate the product when there are no people and/or obstacles in the operating area.



Make sure the roller shutter is disconnected from the power supply when carrying out repairs and activities near your screen.



Always use the services of a professional installer for any repairs and/or activities.





DECLARATION OF CONFORMITY IIA

The manufacturer: **Verano® B.V.**
Bedrijfsweg 8
5683 CP Best
The Netherlands

Declares under its full responsibility that the product:

Ritzscreen®

Which concerns this declaration:

1. complies with the definitions of the Guideline for Machines (89/392/EEG),
2. complies with the Guideline for Low Voltage (73/23/EEG),
3. complies with the EMC- guideline (89/336/EEG),
4. complies with the following harmonised norm NEN-EN 60204,
5. complies with the following harmonised norm NEN-EN 13561.

Best, January 2006.

Frank Pulles
Director

The declaration of conformity is applicable, provided that the product has been installed as indicated in this assembly manual and the use conforms to the assembly manual.

WARRANTY REGISTRATION

Do you want to use the Verano® factory warranty? Visit www.verano.nl/en/service/register-product/ or scan the QR code below to register your product(s) for a 5 year manufacturer's warranty! You will find your Verano® product's unique product code on the back of this booklet, which you will need when filling in the warranty form.

Please also read through the warranty conditions, making sure you know when you are and aren't entitled to the warranty. You can also find this via the above link or QR code.





This is your Verano® product's unique product code.
You can use this code to register the product for the warranty.



For a complete overview of our measure and installation instructions,
please go to **www.verano.nl/en/service/downloads**.